

DigiTrak® AURORA™ App


Strip Chart

Overview

The Aurora Strip Chart application lets you monitor temperature, fluid pressure, and pullback tension data over time. The data is presented on a graph that includes the Warning and Critical levels specified in alarm settings on the Main menu.



Setup



Setup Screen


Select single **1** or dual **2** graphs.

Select the type of data to display in the graph:


- Transmitter temperature
- Transmitter fluid pressure
- TensiTrak force
- TensiTrak fluid pressure

Tap the blue arrow keys or drag the slider to select the amount of time to display.

Tap **OK** to view the strip chart graph.



Strip Chart Graphs

Tap **Settings**  on the bottom of the strip chart to return to the setup screen.

Notes

- Strip chart data is for real-time use only. Data is not stored and cannot be recorded.
- Pressure monitoring requires a fluid pressure transmitter (FPT) and F5® receiver.
- Monitoring pullback tension and pressure requires a TensiTrak® transmitter and F5 receiver.

To stay informed about important updates to your Aurora display and apps, register at access.DigiTrak.com.

DCI delivers the industry's best walkover locating experience.



DIGITAL CONTROL INCORPORATED

dci.australia@digital-control.com ■ www.DigiTrak.com ■ +61.7.5531.4283, 5531.2617 fax

© Oct 2014 Digital Control Incorporated
All rights reserved
403-1600-22-A App Sheet (AS) (Australia)