

DigiTrak® AURORA™ App


Strip Chart

Overview

The Aurora Strip Chart application lets you monitor temperature, fluid pressure, and pullback tension data over time. The data is presented on a graph that includes the Warning and Critical levels specified in alarm settings on the Main menu.



Setup



Setup Screen


Select single **1** or dual **2** graphs.

Select the type of data to display in the graph:


- Transmitter temperature
- Transmitter fluid pressure
- TensiTrak force
- TensiTrak fluid pressure

Tap the blue arrow keys or drag the slider to select the amount of time to display.

Tap **OK** to view the strip chart graph.



Strip Chart Graphs

Tap **Settings**  on the bottom of the strip chart to return to the setup screen.

Notes

- Strip chart data is for real-time use only. Data is not stored and cannot be recorded.
- Pressure monitoring requires a fluid pressure transmitter (FPT) and F5® receiver.
- Monitoring pullback tension and pressure requires a TensiTrak® transmitter and F5 receiver.

To stay informed about important updates to your Aurora display and apps, register at access.DigiTrak.com.

DCI delivers the industry's best walkover locating experience.

